


DH Replacement Kit Installation

LINCOLN WOOD PRODUCTS, INC.

TOOLS REQUIRED: Hammer, Phillips Head Screwdriver, Putty Knife, Pliers and Side Cutter Pliers




- 1. PARTS SUPPLIED:
 - A. Sash
 - B. Jambliners
 - C. 2 Parting Stops (wood/vinyl)
 - D. 4 Sash Stops (white/beige) H. 4 Head Jamb Gaskets
- F. 8 Wood Shims
- G. 32 #7 x 7/8" Screws

(white/beige)

- (for Jambliner Clips)
- E. 8 Jambliner Clips
- 2. Use a putty knife to pry off the inside wood stops. Be careful not to damage them because they can be reused. The bottom
 - sash can now be removed. Disconnect and remove any balance mechanism.

Note: In some applications, removal of the stop may not be necessary. Depending on

the age of the window, you may have to remove metal or vinyl jambliners.









4. Verify the correct fit of the jambliners by placing them against the side jambs. If too tall, cut the bottom of the jambliners in 1/16" increments at a 14° angle. The supplied head jamb gaskets need to be applied to head jamb. Only two are needed - color match to jambliner. Peel off protective backing to expose adhesive and apply gasket to existing head jamb.




5. The metal clips are to be positioned against the jamb, approximately 4" down from the head jamb and 4" up from the sill. Attach these clips into place using the supplied #7 x 7/8" screws. Clips should be installed level and tight to inside stop.



Note: If side jamb has a wide groove which prevents the clip from being fastened flat against the jamb, place the supplied wood shim behind the clip before fastening to keep it level.







Note: Additional clips are supplied and may be used if required on taller units. Place the additional clips approximately at the midpoint of each sash location if necessary.

- 6. Install sash stops into each jambliner at the top of inside track as shown (right). Sash stops must be color matched to jambliner. Note: Sash stops must be applied or the sash or head jamb can be damaged.
- 7. Snap the balances onto the clips by pressing on the outside edges of jambliner. Check to ensure that the "hooks" on the clip interlock with the edge "hooks" on the jambliner.







- **8.** Depending on your window, you will now have 3 options for installing the head parting stop.
 - A) If the original parting stop left a ½" groove in the head, you should use the supplied vinyl parting stop.
 - B) If the original parting stop removed was held in place by a vinyl kerf leg, you may be able to reuse this original stop. If used, you may need to cut it down to fit within the new vinyl jambliners.
 - C) If neither option A or B work, Lincoln has supplied a wood parting stop. This will have to be cut down to fit in between the jambliners. To fasten parting stop to the head, use small finish nails at least 1-1/4" long (not included) leaving a 1/8" gap between the sash and the wood stop.



9. When installing the top sash, engage pin in the outside track of the left balance (tilt pin must be above clutch mechanism) then engage the pin in the outside track of the right balance (above clutch mechanism).



10. Now slide window to horizontal position.



11. Tilt the sash upward until the tilt latches engage in the jambliner. Allow sash to drop and engage clutch mechanism. Repeat procedures 7 through 9 to install lower sash (using inside track). Both sash should fit snug against the jambliner.



12. If applicable, replace the inside stops loosely against balance so that the balance can move freely. If the jambliner is not fully covered by the stops, additional stop material may need to be applied.



This completes the installation of your Lincoln Double Hung Replacement Kit.